



Diaphragm Kit = 5620TFE-DKIT (TS5622VT) or 5620UHMW -DKIT (TS5622VD/TS5622VU)
Includes 1 x 5, 12, 17 and 18

Fluid Housing Kit = 5622VT-FHKIT (TS5622VT) or 5622VD-FHKIT (TS5622VD) or 5622VU-FHKIT (TS5622VU)
Includes 1 x 7, 8, 9, 2 x 10 and 2 x 11 (No washers required for TS5622VD)

Lubrication: All O-Rings & seals must be lubricated with Bimba HT-99, or equivalent, with the exception of the Diaphragm, which must remain dry.

Body Mounting Screw Torque: Acetal (Delrin) requires 14 in lb (1.58 N-m), UHMW requires 7 in lb (0.79 N-m) and Teflon requires 5 in lb (0.56 N-m).

| Item | Part Number | Description | Item | Part Number | Description |
|------|---------------|-----------------------------------|------|--------------|--------------------------|
| 1 | 5620-000-004 | End Cap | 10 | TSD1103-336 | Fluid Housing Screw |
| 2 | A0100478 | Air Hose/Connector Assy, 4mm | 11 | TSD1109-53 | Flat Washer |
| 3 | TSD1109-43 | Mylar Washer | 12 | 5620-000-011 | Diaphragm for TS5622VT |
| 4 | 5620-000-006 | Anti-Rotate Washer | 12* | 5620-000-002 | Diaphragm for VU/VD Type |
| 5 | TSD1400-016A | Piston O-Ring | 13 | TSD1106-13 | Mounting Screw |
| 6 | TSD1003-20 | Air Fitting, 4mm, Elbow | 14 | 918-000-048 | Mounting Bracket |
| 7 | TSD931-75 | Luer Lock Adaptor, Elbow | 15 | 5620-000-003 | Air Cylinder |
| 8 | 5622-000-003 | Fluid Housing for TS5622VT | 16 | 5620-000-005 | Piston |
| 8* | 5622-000-001 | Fluid Housing for TS5622VU | 17 | TSD1150-40 | Spring |
| 8* | 5622D-000-001 | Fluid Housing for TS5622VD | 18 | TSD1400-111A | End Cap O-Ring |
| 9 | TSD931-60 | Tip Adaptor for TS5622VT/TS5622VU | 19 | TSD1120-11 | Retaining Ring |
| 9* | TSD931-91 | Tip Adaptor for TS5622VD | | | |

Dystrybutor